



ALTAIR

Altair[®] FluxMotor[®] 2024

Synchronous machines – Permanent magnets - Inner & outer rotor

Motor Factory – Export

General user information

Contents

1	Motor factory – Export AREA – Home page view	5
1.1	“DOCUMENT”	5
1.2	“ADVANCED TOOLS “	5
1.3	“SYSTEM”	5
2	Make a report	7
2.1	Overview	7
2.2	Area to build the report	7
2.3	Steps to build and export a report	8
2.4	Section selection	8
2.4.1	List of sections available to build the report	8
2.4.2	Selection of sections	9
2.5	Export information	10
3	Export a script	11
3.1	Overview	11
3.2	Area to build the script export	11
4	Build and export a connector for Altair® HyperStudy®	12
4.1	Overview	12
4.2	Area to build a connector	12
4.3	Steps to build and export a connector	13
4.4	Test selection	13
4.5	Test configuration	14
4.6	Parameters for HyperStudy®	15
4.6.1	Selection of design parameters	15
4.6.2	Selection of test data	16
4.7	Export information	17
4.8	Get back Altair® HyperStudy® results in Altair® FluxMotor®	19
4.9	Connection between FluxMotor® and HyperStudy®	20
	Warning: Mandatory synchronization between connector and FluxMotor versions	20
5	Build and export a model in Altair® Flux® 2D environment	22
5.1	Overview	22
5.2	Area to build and to export a model to Flux® 2D environment.	22
5.3	Steps to build and export a model to Flux® 2D environment	23
5.4	Test selection	24
5.5	Test configuration	24
5.6	Export information	25

5.7	Available models to be exported and user inputs-----	26
5.7.1	Overview-----	26
5.7.2	Without scenario – Current source – Motor and generator – Basic model-----	26
5.7.2.1	Positioning and objective -----	26
5.7.2.2	Settings-----	26
5.7.2.3	Standard inputs-----	27
5.7.2.4	Advanced inputs-----	27
5.7.3	Without scenario – Current source – Motor and generator – Thermal model -----	28
5.7.3.1	Positioning and objective -----	28
5.7.3.2	Settings-----	28
5.7.3.3	Standard inputs-----	28
5.7.3.4	Advanced inputs-----	28
5.7.4	Characterization – Open circuit – Motor & Generator – Back – emf -----	29
5.7.4.1	Positioning and objective -----	29
5.7.4.2	Settings-----	29
5.7.4.3	Standard inputs-----	29
5.7.4.4	Advanced inputs-----	29
5.7.5	Working point – Sine wave – Motor – I, Ψ , N-----	30
5.7.5.1	Positioning and objective -----	30
5.7.5.2	Settings-----	30
5.7.5.3	Standard inputs-----	31
5.7.5.4	Advanced inputs-----	32
5.7.6	Performance mapping – Sine wave – Motor – Efficiency map - FeMT-----	33
5.7.6.1	Positioning and objective -----	33
5.7.6.2	Settings-----	33
5.7.6.3	Standard inputs-----	33
5.7.6.4	Advanced inputs-----	34
5.7.6.5	Export inputs -----	34
5.7.7	List of generic advanced inputs-----	34
6	Build and export a model in Altair® Flux® SKEW environment-----	36
6.1	Overview -----	36
6.2	Area to build and to export a model to Flux® SKEW environment-----	36
6.3	Particularities in building and to exporting a model to Flux® SKEW environment-----	37
7	Build and export a model in Altair® Flux® 3D environment-----	38
7.1	Overview -----	38
7.2	Area to build and to export a model to Flux® 3D environment-----	38
7.3	Particularities in building and exporting a model to Flux® 3D environment-----	39
8	Build and export a model in Altair® FLOW SIMULATOR™ environment-----	40
8.1	Overview -----	40
8.2	Area to build and to export a model to Flow Simulator™ environment-----	40
8.3	Steps to build an export Flow Simulator™-----	41
8.3.1	Introduction-----	41
8.3.2	Test selection-----	41
8.3.3	Test configuration-----	41
8.3.4	Export information-----	41
8.4	Available models to be exported and user inputs-----	43
8.4.1	Overview-----	43
8.4.2	Characterization – Thermal -Motor & Generator – Steady State-----	43

8.4.2.1	Positioning and objective	43
8.4.2.2	Settings	43
8.4.2.3	Standard inputs	43
8.4.2.4	Advanced inputs	43
9	Export to SYSTEM	44
9.1	Overview	44
9.2	Area to export LUT	44
9.3	Steps to build an export LUT	45
9.3.1	Introduction	45
9.3.2	Test selection	45
9.3.3	Test configuration	45
9.3.4	Export information	46
9.4	FMU format files	47
9.4.1	Compatibility	47
9.4.2	A C/C++ compiler is needed	48
9.4.2.1	C/C++ compiler / System requirements	48
9.4.2.2	Access path of the C/C++ Compiler	48
9.4.3	Import FMU data in Altair® Activate®	49
9.5	MAT format files	52
9.5.1	Introduction	52

1 MOTOR FACTORY – EXPORT AREA – HOME PAGE VIEW

The area “EXPORT” of Motor Factory groups two main families of functions:

1.1 “DOCUMENT”

In “DOCUMENT”, the function “REPORT” allows building reports automatically to describe all the work achieved for the design as well as for the tests.

Then, the function “SCRIPT” allows to build and export a python script of a current motor in the application Script Factory or in a targeted folder.

1.2 “ADVANCED TOOLS “


In “ADVANCED TOOLS”, the function “HYPERSTUDY” allows to build and export a connector in Altair® HyperStudy® for performing studies like optimization or Design Of Experiment (DOE).

Then, the functions “FLUX 2D”, FLUX SKEW, FLUX 3D allow to build and export a model in Altair® Flux® environment (2D, Skew or 3D) for performing advanced studies either with magneto static or transient applications.

Finally, the function “FLOW SIMULATOR” allows to export the thermal model to Altair® Flow Simulator®M for visualizing the machine lumped thermal circuit and for performing advanced studies regarding its thermal steady state behavior.

1.3 “SYSTEM”

The function “SYSTEM” allows exporting files in FMU (Functional Mock-up Unit) format file or in MAT format file from FluxMotor®.



Motor Factory - EXPORT area


1	Selection of the EXPORT area of Motor Factory.
2	Access the area "REPORT" in which a report can be made
3	Access the area "SCRIPT" for generating a python file in which all the needed command lines are written to rebuild the motor
4	Access the area "HYPERSTUDY" in which a connector can be made and sent to HyperStudy®
5	Access the area "FLUX2D" in which a model can be made and sent to Altair® Flux® 2D
6	Access the area "FLUX SKEW" in which a model can be made and sent to Flux® Skew
7	Access the area "FLUX3D" in which a model can be made and sent to Altair® Flux® 3D
8	Access the area "FLOW SIMULATOR" through which the thermal model of the machine can be analyzed in Flow Simulator™
9	Access the area "SYSTEM" in which a data files can be exported in FMU format files or in MAT format files for PSIM or Awtivate

2 MAKE A REPORT

2.1 Overview

The aim of this export is to build and quickly export a report showing all the work achieved to design and test the machine. As a result, the report can be exported in a pdf or html file format. It can also be attached to the motor in the "Motor Catalog" or simply displayed in the report area.

2.2 Area to build the report



Motor Factory – EXPORT AREA – Export a report

1	Selection of the EXPORT area of Motor Factory.
2	Access the area in which a report can be made
3	Zone to visualize the report (= preview)
4	4 steps to build the report which user need
5	Buttons to validate inputs, display a preview and export a report


2.3 Steps to build and export a report

Five steps are needed to build and export a report: In EXPORT / DOCUMENT / REPORT area:

- 1) Select the sections to write dealing with the design
- 2) Select the sections to write dealing with the tests
- 3) Select the sections to write dealing with the materials
- 4) Select the “saved test results” you want to add as archive in the report
- 5) Define the export information

2.4 Section selection

2.4.1 List of sections available to build the report



Motor Factory - EXPORT AREA – Export a report – Chapters to be selected

1	Chapters to describe the DESIGN. Machine, Rotor and Stator characteristics.
2	Chapters to describe the TEST results. All the test results are available as soon as the corresponding computations are performed.
3	List of materials used to build the machine can be added to the report with all their physical properties.
4	Archive groups all the tests which have been saved during the process. These can be added to the report. Note: A maximum of five results per test can be added to the report.
5	Button to apply the selection of the user input selections (selection of chapters)
6	Button to restore default values.

2.4.2 Selection of sections

2.1 Characterization - Open circuit - Motor & Generator - Back emf

2.1.1 Configuration

2.1.1.1 Inputs

Name	Value	Name	Value	Name	Value
Context					
Family	Characterization	Package	Open circuit	Convention	Motor and Generator
Test	Back emf				
Standard parameters					
Speed (rpm)	750.0				
Advanced parameters					
Max. comp. / elec. period	21	Max. harmonic order	20		
Motor initial position (deg)	44.997	Mesh order	2nd	Angap mesh coefficient	1.5

2.1.1.2 Settings

Name	Value	Name	Value	Name	Value
Thermal					
Magnet temperature Tmag (°C)	20.0				

2.1.1.3 Winding and Magnet characteristics


Name	Value	Name	Value	Name	Value
Winding					
Winding connection	Wye				
Magnets					
Magnet temperature Tmag (°C)	20.0				
Magnet name	Magnet	Material name	REF.SmCo_1040_1600	Material reference temp: Tref (°C)	20.0
Remanent induction at Tref (T)	1.04	Intrinsic coercive field at Tref (A/m)	1.8 E6	Relative permeability at Tref	1.04
Remanent induction at Tmag (T)	1.04	Intrinsic coercive field at Tmag (A/m)	1.8 E6	Relative permeability at Tmag	1.04

2.1.2 Main results

Motor Factory - EXPORT AREA – Export a report – Chapters to be selected

1	Section names are shortcuts for displaying the corresponding section of the report
2	Check the section to add chapters to the report
3	Button “Preview” considers the selected chapters and displays the report

2.5 Export information



Motor Factory - EXPORT AREA – Export a report – Export information


1	Access to the area in which export parameters can be defined
2	A file name must be written (Default name = "Report")
3	The file format must be chosen (pdf or html) to build the report
4	A folder in which storing the report must be selected via the browser
5	It is possible to attach the report (HTML or PDF file) to the motor in the "Motor Catalog"
6	Button to export the report by considering all the previous defined parameters

3 EXPORT A SCRIPT

3.1 Overview

Next to the function “Report”, the function “Script” gives the capability to build and export a python script file, in which all the needed command lines are written to rebuild the considered motor. The script is generated with all the needed sections and sub-sections in Motor Factory, dedicated to the design, the test, and the exports. Then Script Factory can be used to automate some study such like running serial tests or serial design configurations.

3.2 Area to build the script export



Motor Factory – EXPORT AREA – Export a python script

1	In Motor Factory select EXPORT / SCRIPT environment.
2	The EXPORT / SCRIPT environment user inputs allow to define the name and the location of the new script file + the name of the motor to be rebuilt from the new python script file, with the catalog name in which it will be stored. Note: Without defining other names for the motor and/or the catalog, the original motor would be overwritten while running the new python script file.
3	Button to build and to export the resulting python file.
4	Button to build and export the resulting python file, and then to open it directly in the Script Factory

4 BUILD AND EXPORT A CONNECTOR FOR ALTAIR® HYPERSTUDY®

4.1 Overview


The aim of this export is to build a connector, allowing Altair® HyperStudy® to drive Altair® FluxMotor® for performing motor optimizations based on the computation processes embedded into FluxMotor®.

This can be done for an eligible test list by using input/output parameters defined in FluxMotor®.

Then, after having performing studies with HyperStudy® (Optimization or Design Of Experiment -DOE- for instance), the results can be visualized by selecting the resulting machine in the “Motor Catalog”.

Note: This functionality is not yet implemented for polyphase machines. It will be addressed in a future version.

4.2 Area to build a connector



Motor Factory – EXPORT AREA – Export connector for HyperStudy®

1	Selection of the EXPORT area of Motor Factory.
2	Access the area in which a connector for HyperStudy® can be made
3	Zone to visualize either the overview of the selected test or the corresponding user input/output parameters
4	4 steps to build the connector to be exported for HyperStudy®
5	Buttons to validate inputs, display a preview and export the built connector for HyperStudy®

4.3 Steps to build and export a connector

In EXPORT / ADVANCED TOOLS / HYPERSTUDY area, 4 steps are needed to build and export a report:


- 1) Select the test which will be performed by HyperStudy®
- 2) Define the test configuration, that means the user inputs/outputs parameters needed to define the test (settings and user inputs of the considered test)
- 3) Select the inputs/outputs parameters for performing studies with HyperStudy®
- 4) Define the export information

4.4 Test selection

In the current version of FluxMotor®, 12 tests can be selected for Synchronous machines with permanent magnets:

- Characterization / Open circuit / Motor & generator / Cogging
- Characterization / Open circuit / Motor & generator / Back emf
- Characterization / Thermal / Motor & generator / Steady state
- Working point / Sine wave / Motor / I-Ψ-N
- Working point / Sine wave / Motor / T-N
- Working point / Sine wave / Motor / I-U
- Working point / Sine wave / Generator / T-N
- Working point / Sine wave / Generator / I-U
- Working point / Square wave / Motor / Forced I
- Performance mapping / Sine wave / Motor / Efficiency mapping
- Performance mapping / Sine wave / Generator / Efficiency mapping
- Mechanics / NVH / Working point / I-Ψ-N

When a test is selected, the corresponding overview is displayed in the center of the screen, showing the main inputs to be considered.




Motor Factory – EXPORT AREA – Export connector for HyperStudy®

1	Selection of a test to be performed by HyperStudy®
2	Display of general information (overview) dealing with the selected test

4.5 Test configuration

After selecting a test, the corresponding test inputs (settings and user inputs) must be defined. This allows to define the initial conditions for testing.



Motor Factory – EXPORT AREA – Export connector for HyperStudy®


1	Overview of the selected test is displayed.
2	User inputs can be defined in the test area.

Note: The user help information about the test parameters is defined in the user help guide of the corresponding test. Please refer to the corresponding section.

4.6 Parameters for HyperStudy®

This section allows to select the parameters which must be available for the optimization in HyperStudy®. These can be design parameters, parameters to define the test conditions (inputs and/or settings) or test results.

4.6.1 Selection of design parameters




Motor Factory – EXPORT AREA – Export connector for HyperStudy®
Design parameters selection

1	Tab to be expanded to choose input/output parameters for HyperStudy®
2	Area in which input/output parameters are stored for HyperStudy®
3	Shortcuts to select the part of the design to be considered for the selection of parameters
4	All available design inputs are displayed. The corresponding dimension is highlighted when selected - arrow (5). When a parameter is chosen, the associated box is ticked (4), and the parameter name is stored in the selected parameters area (2).
5	Arrow illustrating the selected design input parameter
6	Button to validate the previous choices

Note: Data which are given by the user are written in blue. They are inputs data. Data resulting from internal computations (outputs) are written in black. This allows the users to quickly differentiate between the input data and output data inside data tables.

4.6.2 Selection of test data

The test data groups test results as well as the user inputs and settings. All these data can be selected for optimization in HyperStudy®.



Motor Factory – EXPORT AREA – Export connector for HyperStudy® – Test data selection

1	Tab to be expanded to choose input/output parameters for HyperStudy®
2	Area in which input/output parameters are stored for HyperStudy®
3	Shortcuts to select the part of the test condition and test results to be considered for the selection of parameters
4	All available test data (test results as well as user inputs) are displayed. When a data is chosen, the associated box is ticked (4), and the parameter name is stored in the selected parameters area (2).
5	Display of data which can be selected for HyperStudy® studies
6	Button to validate the previous choices


Note: Data which are given by the user are written in blue. These are inputs data. Data resulting from internal computations (outputs) are written in black. This allows the users to quickly differentiate between the input data and output data inside data tables.

4.7 Export information

The last step for building the connector for HyperStudy® is to define the export information.

There are three data to be defined:

- The name of the connector
- The folder in which the connector must be stored
- The last answer, “Save iteration (Yes/No)” indicates if the results of the HyperStudy® must be stored in a dedicated catalog of Motor Catalog application. When “Yes” is answered all the resulting motors can be visualized in Motor Catalog, and then these can be edited in the Motor Factory very quickly.




Motor Factory – EXPORT AREA – Export connector for HyperStudy® – Export information

1	Tab to be expanded to define the export information for HyperStudy®
2	Area in which the export parameters to be defined are listed
3	Button to validate the previous choices
4	Buttons to finalize the export.
4a	To finalize this operation from FluxMotor, a first button allows to directly and automatically launches HyperStudy, builds and load the connector to perform the optimization.
4b	Button to finalize the export of the connector. When one clicks on this button opened the folder where the connector is stored.

Note: When one clicks on this button (4a), HyperStudy is automatically opened, with the connector built by FluxMotor uploaded. The studies can be initialized and run immediately in HyperStudy. The input variables as well as the Output responses that have been selected in FluxMotor are automatically identified and uploaded.

Note: When data is missing in the third table; "Parameters for HyperStudy®" for instance, an error message is displayed in the red color font which indicates, what is missing and where. If all the needed information is missing, exporting a connector is not allowed.




Motor Factory – EXPORT AREA – Export connector for HyperStudy® – Error message

1	Error message written in red font
2	The two buttons to export the connector and run launch HyperStudy are not active if the needed data is missing

4.8 Get back Altair® HyperStudy® results in Altair® FluxMotor®

All the motors resulting from the test runs performed with HyperStudy® can be used back in Motor Catalog of FluxMotor®, and then these can be edited in Motor Factory very quickly.




Motor Catalog – Visualization of results got from HyperStudy®

1	A catalog is automatically built by using the name of the connector defined by the user
2	All the test runs performed with HyperStudy® are stored in the dedicated catalog
3	Each motor can be selected, visualized, and edited in the Motor Factory, to be evaluated more in depth

4.9 Connection between FluxMotor® and HyperStudy®

Before starting new studies in HyperStudy® by using connectors exported from FluxMotor®, FluxMotor® must be registered as a new solver script in HyperStudy®. This must be defined only while using the coupling for the first time.



Connection between FluxMotor® and HyperStudy®

1	Open the area in HyperStudy® to register FluxMotor® 2024 script Path where FluxMotors.exe must be selected to be registered as a new solver in HyperStudy®.
2	This must be defined only when using the coupling for the first time. Note: FluxMotors.exe with a "s" at the end of FluxMotors. Note: Since the version 2022.1 of HyperStudy, the FluxMotor solver script is automatically registered, when the default path installation is selected while installing Flux and FluxMotor

Note: The new auto generating the HyperStudy Study in HyperStudy Application (described above) allows to automatically register FluxMotor® as a new solver script in HyperStudy®. If HyperStudy is not install in the same folder (by default : C:\Program Files\Altair\2024\hwdesktop\hst), the path must be defined in the user preferences via the supervisor of FluxMotor (Path to HyperStudy – Needed for HyperStudy export – Ref. 3 below)

Warning: Mandatory synchronization between connector and FluxMotor versions

The connectors used in HyperStudy must be synchronized with the FluxMotor solver version.

An error message (inside the log files) is generated while performing HyperStudy studies with a connector provided with a former version of FluxMotor solver.

A connector provided with FluxMotor version N-1 (or older) cannot be used in HyperStudy where the FluxMotor Solver Version N (or newest) is selected.

Since the FluxMotor 2022.3 version, each time a connector is generated, a ConnectorUpdater.py file is provided and located in the same folder as the connector.

Thanks to this script, the user can update an older HyperStudy connector generated with a former version of FluxMotor.

Please refer to the document MotorFactory_Introduction.pdf for additional information in the section dedicated to HyperStudy.

1

2

3

4

5

Path to HyperStudy – Needed for HyperStudy export – It must be defined in the user preferences (Supervisor of FluxMotor)

5 BUILD AND EXPORT A MODEL IN ALTAIR® FLUX® 2D ENVIRONMENT

5.1 Overview

The aim of this export is to provide a python file which allows to get a full parametrized model ready to be used in Altair® Flux® 2D environment.


In the current version, models can be exported for static application or transient application in Altair® Flux® 2D environment.

Four models can be exported to Flux® 2D environment:

Application	Model family	Package	Convention	Model / Test
STATIC	Without solving scenario	Current source	Motor & Generator	Basic model
TRANSIENT	Characterization	Open circuit	Motor & Generator	Back-EMF
	Working point	Sine wave	Motor	I-Ψ-N
	Performance mapping	Sine wave	Motor	Eff. Map. - FEMT

Note: These models are considered for inner rotor machines and outer rotor machines and for 3-Phase and polyphase machines as well, excepting the last one (performance mapping) which is only implemented for inner rotor 3-Phase machines only.

5.2 Area to build and to export a model to Flux® 2D environment.



Motor Factory – EXPORT AREA – Export model for Flux® 2D environment

1	Selection of the EXPORT area of Motor Factory.
2	Access the area in which a model for Flux® 2D environment can be made
3	Zone to visualize the overview of the selected model to be exported
4	Click on the tab to select the application (STATIC or TRANSIENT)
5	3 steps to build the model to be exported for Flux® 2D environment
6	Button to validate inputs before building the model in Flux® 2D environment.
7	Exports the python file for building the model in Flux® 2D environment or launch the project directly in Flux® 2D.

5.3 Steps to build and export a model to Flux® 2D environment

In EXPORT / ADVANCED TOOLS / FLUX2D area, one must indicate that on which application of Flux® 2D environment, the models must be built: static application or transient application.


Then, the 3 next steps are:

- 1) Define the type of scenario one wants to get in Flux® 2D environment (Test selection).
This means the simulation, that one wants to perform in Flux® 2D environment for evaluating the electromagnetic behavior of the considered machine.
- 2) Define the test configuration. This is to give an initial value for the user inputs, which will be set in the scenario of the simulation available in the Flux® 2D model.

Note: For each Flux® 2D model available in the current version, a short description of the user inputs is done in the following sections.

- 3) Define the export information

The resulting models are fully parameterized, and these are built in Flux® 2D environment for static or transient applications.




Motor Factory – EXPORT AREA – Export model for Flux® 2D environment

1	Select application (STATIC or TRANSIENT) in which the model must be built in Flux® 2D
2	Choose one scenario (or test) to be provided
3	Define the initial conditions for the simulation process in Flux® 2D environment
4	Define export information

5.4 Test selection

After selecting an application type (STATIC or TRANSIENT), the corresponding test inputs (settings and user inputs) must be defined. This allows to define the initial conditions for testing.




Motor Factory – EXPORT AREA – Export a model for Flux® 2D – Test selection

1	Selection of application (STATIC or TRANSIENT) in which the model must be built for Flux® 2D
2	Tab to choose one scenario (or test) to be provided
3	Selection of the scenario (or test) to be provided
4	Button to validate the previous choices

Note: The user help information about the test parameters is defined in the user help guide of the corresponding test. Please refer to the corresponding section.

5.5 Test configuration

After selecting an application type (STATIC or TRANSIENT), the corresponding scenario (or test) inputs (settings and user inputs) must be defined. This allows to define the initial conditions for the simulation process in Flux® 2D environment.




Motor Factory – EXPORT AREA – Export a model for Flux® 2D -

1	Tab to define the initial conditions for the simulation process in Flux® 2D environment
2	Settings like thermal conditions can be defined
3	User inputs dealing with the considered test can be defined
4	The tab corresponding to advanced parameters can be expanded. Advanced parameters can also be defined if needed.
5	Button to validate the previous choices

5.6 Export information

The last step for building a model for Flux® 2D is to define the export information. There are three data to be defined:


- The name of the python file which will build the model in Flux® 2D environment.
- The folder in which the provided file must be stored
- The last answer “Full geometry “ allows the user to get a full geometry in the provided model, even if it is possible to work with a reduced model considering the number of poles and the number of slots.



Motor Factory – EXPORT AREA – Export model for Flux® 2D – Export information

1	Tab to be expanded to define export information for Flux® 2D
2	Area in which the export parameters to be defined are listed
3	Button to validate the previous choices
4	Button to finalize the export of the model. When one clicks on this button, the folder gets opened where the python file to build the model is stored.
5	Button to finalize the export of the model. This button launches Flux® 2D and builds the model.

Note 1: When data is missing in third table; “Export information” for instance, an error message is displayed in the red colored font which indicates what data is missing. If all the needed information is missing, exporting a model is not allowed.



Motor Factory – EXPORT AREA – Export model for Flux® 2D – Error message

1	Error message displayed in the red colored font
2	The button to export the model is not active if all the needed data are missing

Note: Exporting a model to Flux® 2D (i.e. provide the python file to build the model) can take a few seconds. This is since parameters like initial position of the rotor must be computed first by using internal processes, and then the simulation scenario must be considered.

5.7 Available models to be exported and user inputs

5.7.1 Overview

All the models to be exported are first classified by considering the type of application, for which they are built (STATIC or TRANSIENT). Then, for the tests in Motor Factory Test environment, the models are associated with a convention of operating (Motor or Generator) and grouped into packages itself to get classified into model families.

In the current version of FluxMotor® four models can be exported to Flux® 2D environment:

Application	Model family	Package	Convention	Model / Test
STATIC	Without solving scenario	Current source	Motor & Generator	Basic model
TRANSIENT	Characterization	Open circuit	Motor & Generator	Back emf
	Working point	Sine wave	Motor	I-Ψ-N
	Performance mapping	Sine wave	Motor	Eff. Map. - FEMT


The following section give a short description of all the models available for exportation to Altair® Flux® 2D environment.

5.7.2 Without scenario – Current source – Motor and generator – Basic model

5.7.2.1 Positioning and objective

This export allows the users to build a model in Flux® 2D, static application to perform magneto-static and multi-static simulations. User inputs like, line current and control angle are predefined to get quick access into Flux® 2D environment for performing computations.

The resulting model is fully parameterized, and it is built in Flux® 2D environment, static application.



The following section describes all the user inputs to initialize the exported model. All these parameters can be modified in Flux® 2D environment, if needed.

5.7.2.2 Settings

One button gives access to the following setting definition:

- Temperature of magnets

For more details, refer to the section dealing with the test settings.

5.7.2.3 Standard inputs


1) Line current, rms

The line current supplied to the machine: **“Line current, rms”** (*Line current, rms value*) must be provided.

2) Control angle

Considering the vector diagram shown below, the **“Control angle”** is the angle between the electromotive force E and the electrical current (J) ($\Psi = (E, J)$).

It is an electrical angle. The default value is 45 degrees. It must be set in a range of -90 to 90 degrees. This range of values covers all the possible working point in motor convention.



5.7.2.4 Advanced inputs

The list of advanced inputs dedicated to this export are listed below. For more details, please refer to the section 5.7.7 - List of generic advanced inputs.

1) Rotor initial position mode

By default, the **“Rotor initial position mode”** is set to **“Auto”**.

2) Rotor initial position

3) Mesh order

The default level is second order mesh.

4) Airgap mesh coefficient

Airgap mesh coefficient is set to 1.5 by default.


5.7.3 Without scenario – Current source – Motor and generator – Thermal model

5.7.3.1 Positioning and objective

This export allows the users to build a model in Flux® 2D, static application to perform thermal-static simulations. User inputs are the ones defined in test Characterization – Thermal – Motor & Generator – Steady state, to get access into Flux® 2D environment for performing computations.

Note: This functionality is not implemented for polyphase machines. It will be addressed in a future version.

The resulting model is fully parameterized, and it is built in Flux® 2D environment, thermal static application.



The following section describes all the user inputs to initialize the exported model. All these parameters can be modified in Flux® 2D environment, if needed.

5.7.3.2 Settings

One button gives access to the following setting definition:

- External fluid temperature

For more details, refer to the section dealing with the test settings.

5.7.3.3 Standard inputs

5) Speed

The speed of the machine to be considered.

6) Set of losses

The losses to be defined are the following ones:

- Stator Joule losses
- Stator iron losses
- Magnet losses
- Rotor iron losses
- Mechanical losses

5.7.3.4 Advanced inputs

There are no advanced inputs required for this export.

5.7.4 Characterization – Open circuit – Motor & Generator – Back – emf

5.7.4.1 Positioning and objective

The aim of the test “**Characterization - Open circuit – Motor & Generator - Back-EMF**” is to characterize the behavior of the machine, when running in open circuit state.

The resulting model is fully parameterized, and it is built in Flux® 2D environment, transient application.

The following section describes all the user inputs to initialize the exported model.

All these parameters can be modified in Flux® 2D environment, if needed.

5.7.4.2 Settings

One button gives access to the following setting definition:

- Temperature of active components: winding and magnets

For more details, refer to the section dealing with the test settings.

5.7.4.3 Standard inputs

1) Speed

The only default input parameter is the operated speed of the machine to be used in the back-EMF test.

5.7.4.4 Advanced inputs

The list of advanced inputs dedicated to this export are listed below.

For more details, please refer to the section 5.7.7 - List of generic advanced inputs.

1) Number of computations per electrical period

The default value is equal to 50. The minimum allowed value is 13.

2) Number of computed electrical periods

The default value is equal to 2. The minimum allowed value is 1 and the maximum value is equal to 10.

3) Rotor initial position

By default, the “**Rotor initial position**” is set to “**Auto**”.

4) Mesh order

The default level is second order mesh.

5) Airgap mesh coefficient


Airgap mesh coefficient is set to 1.5 by default.

5.7.5 Working point – Sine wave – Motor – I, Ψ , N

5.7.5.1 Positioning and objective

The aim of the test **“Working point – Sine wave – Motor – I, Ψ , N”** is to characterize the behavior of the machine when operating at the targeted input values I, Ψ , N (Magnitude of current, Control angle, Speed). Hence, these three inputs are enough to impose a precise working point.

The resulting model is fully parameterized, and it is built in Flux® 2D environment, transient application.



The results of this test give an overview of the electromagnetic analysis of the machine considering its topology. It also gives the capability to make comparisons between results obtained from the measurements and those with the FluxMotor®.

The following section describes all the user inputs to initialize the exported model. All these parameters can be modified in Flux® 2D environment, if needed.

5.7.5.2 Settings

One button gives access to the following setting definition:

- Temperature of active components: winding and magnets

For more details, refer to the section dealing with the test settings.

5.7.5.3 Standard inputs


1) Line current, rms

The line current supplied to the machine: “**Line current, rms**” (*Line current, rms value*) must be provided.

2) Control angle

Considering the vector diagram shown below, the “**Control angle**” is the angle between the electromotive force E and the electrical current (J) ($\Psi = (E, J)$).

It is an electrical angle. The default value is 45 degrees. It must be set in a range of -90 to 90 degrees. This range of values covers all the possible working point in motor convention.



3) Speed

The imposed “**Speed**” (*Speed*) of the machine must be set.

4) Represented coil conductors

In transient application, it is possible to export a project into Flux® environment, where the elementary wires will be modeled with solid conductors. The geometry, the meshing and the corresponding electric circuit will be defined to well represent these.

Three choices are possible:

- “No”: The coils will be represented with face regions. The elementary wires won’t be represented in the Finite Element model (Flux®).
- “One phase”: The elementary wires will be represented for only one phase. This will allow to compute AC losses for conductors into the first phase. This choice allows to get a good ratio between the quality of results and computation time.
- “All phases”: The elementary wires will be represented into all the phases

5.7.5.4 Advanced inputs

The list of advanced inputs dedicated to this export are listed below.
For more details, please refer to the section 5.7.7 - List of generic advanced inputs.

- 1) Number of computations per electrical period

The default value is equal to 50. The minimum allowed value is 13.

- 2) Number of computed electrical periods

The default value is equal to 2. The minimum allowed value is 1 and the maximum value is equal to 10.

- 3) Rotor initial position

By default, the “**Rotor initial position**” is set to “**Auto**”.

- 4) Mesh order

The default level is second order mesh.

- 5) Airgap mesh coefficient

Airgap mesh coefficient is set to 1.5 by default.

5.7.6 Performance mapping – Sine wave – Motor – Efficiency map - FeMT

5.7.6.1 Positioning and objective


The aim of the test “**Performance mapping – Sine wave – Motor – Efficiency map - FeMT**” is to characterize the machine efficiency map, launching a set of transient simulations which allows very high accuracy.

Note: This test is not available for polyphase machines.

The resulting model is fully parameterized, and it is built in Flux® 2D environment, transient application. To run this test, Flux® 2D offers a dedicated toolbox called Flux e-Machine Toolbox (FeMT), which automatically manage the set of simulations and their postprocessing to build complete and accurate maps.

Through this export, the users will obtain a FeMT project ready to be solved. Additionally, the Flux® 2D project used by FeMT is also available.

Note: It should be noted that, even if the export process is quite fast, the simulation in FeMT is based on a big set of transient simulations, that usually requires a high computation time. For more information, refer to FeMT Help.



The following section describes all the user inputs to initialize the exported model.

5.7.6.2 Settings

One button gives access to the following setting definition:

- Temperature of active components: winding and magnets

For more details, refer to the section dealing with the test settings.

5.7.6.3 Standard inputs

- 1) Maximum phase current, rms

The maximum phase current supplied to the machine: “**Phase current rms**” (*Maximum phase current, rms value*) must be provided.

- 2) Maximum phase voltage, rms

The maximum phase voltage supplied to the machine: “**Phase voltage rms**” (*Maximum phase voltage, rms value*) must be provided.

- 3) Command mode

The user can choose between two types of command modes:

- Maximum Torque Per Voltage (MTPV)
- Maximum Torque Per Amps (MPTA)

Note: MTPV guarantees the maximum mechanical torque (or mechanical power) for each speed, considering the electrical limits established (i.e., max phase current and voltage). This command mode shows the full potential of the machine, but it is also the most difficult command mode to implement in terms of control and drive. On the contrary, MTPA is the easiest implementation for control and drive, but some regions of the torque-speed map that are attainable for MTPV are no longer available for a MTPA strategy.

4) Speed

The maximum "**Speed**" (*Maximum speed*) of the machine must be set.

5.7.6.4 Advanced inputs

The list of advanced inputs dedicated to this export are presented below.
For more details, please refer to the section 5.7.7 - List of generic advanced inputs.

1) Number of computations per electrical period

The default value is equal to 30. The minimum allowed value is 13.

2) Number of computations for Jd, Jq

The default value is equal to 8. The minimum allowed value is 5.

3) Number of computations for speed

The default value is equal to 10. The minimum allowed value is 5.

4) Mesh order

The default level is second order mesh.

5) Airgap mesh coefficient

Airgap mesh coefficient is set to 1.5 by default.

5.7.6.5 Export inputs

This test offers an additional input in the export information.

1) Generate Flux project.

The FeMT project is automatically generated by the export process. The source Flux® 2D project is created, only if this input is set to "Yes". Its default value is "No".

5.7.7 List of generic advanced inputs

1) Number of computations per electrical period

The number of computations per electrical period "**No. comp. / elec. period**" (*Number of computations per electrical period*) influences the accuracy of results and the computation time.
The default value is 50. The minimum allowed value is 13. This default value provides a good balance between the accuracy of results and computation time.

2) Number of computed electrical periods

The default value is 2. The minimum allowed value is 1 and the maximum value is equal to 10.

3) Rotor initial position

By default, the "**Rotor initial position**" is set to "Auto".

When the “**Rotor initial position mode**” is set to “**Auto**”, the initial position of the rotor is automatically defined by an internal process. The resulting relative angular position corresponds to the alignment between the axis of the stator phase 1 (reference phase) and the direct axis of the rotor north pole.

When the “**Rotor initial position**” is set to “User input” (i.e. toggle button on the right), the initial position of the rotor considered for computation must be set by the user in the field « **Rotor initial position** ». The default value is equal to 0. The range of possible values is [-360, 360].

For more details, please refer to the document: MotorFactory_SMPM_IOR_3PH_Test_Introduction – section “Rotor and stator relative position”.

4) Mesh order

To get the results, the computation is performed using a Finite Element Modeling. The geometry of the machine is meshed. Two levels of meshing can be considered for this finite element calculation: first order and second order. This parameter influences the accuracy of results and the computation time.

By default, second order mesh is used.

5) Airgap mesh coefficient

The advanced user input “**Airgap mesh coefficient**” is a coefficient which adjusts the size of mesh elements inside the airgap. When one decreases the value of “**Airgap mesh coefficient**”, the size of the mesh elements reduces, thus increasing the mesh density inside the airgap and the accuracy of results.

The imposed Mesh Point (size of mesh elements touching points of the geometry) is described as:

$$\text{Mesh Point} = (\text{airgap}) \times (\text{airgap mesh coefficient})$$

Airgap mesh coefficient is set to 1.5 by default.

The variation range of values for this parameter is [0.05; 2].

0.05 gives a very high mesh density, and 2 gives a very coarse mesh density.

Caution:

Be aware, a very high mesh density does not always mean a better result quality. However, this always leads to a huge number of nodes in the corresponding finite element model. So, it means the need of huge numerical memory, which increase the respective computation time considerably.

6 BUILD AND EXPORT A MODEL IN ALTAIR® FLUX® SKEW ENVIRONMENT

6.1 Overview

The aim of this export is to provide a python file which allows to get a full parametrized model ready to be used in Flux® SKEW environment.


All the models to be exported are first classified by considering the type of application for which they are built (STATIC or TRANSIENT). Then, for the tests in Motor Factory Test environment, the models are associated with a convention of operating (Motor or Generator) and grouped into packages itself to get classified into model families.

In the current version of FluxMotor® three models can be exported to Flux® SKEW environment:

Application	Model family	Package	Convention	Model / Test
STATIC	Without solving scenario	Current source	Motor & Generator	Basic model
TRANSIENT	Characterization	Open circuit	Motor & Generator	Back emf
	Working point	Sine wave	Motor	I-Ψ-N

The following section give a short description of all the models available for exportation to Flux® 2D environment.

6.2 Area to build and to export a model to Flux® SKEW environment



Motor Factory – EXPORT AREA – Export model for Flux® Skew environment


1	Selection of the EXPORT area of Motor Factory.
2	Access to the area in which a model for Flux® Skew environment can be made
3	Zone to visualize the overview of the selected model to be exported
4	Click on the tab to select the application (STATIC or TRANSIENT)
5	3 steps to build the model to be exported for Flux® Skew environment
6	Button to validate inputs and export the python file for building the model in Flux® Skew environment.
7	Buttons to export the python file for building the model in Flux® Skew environment, or launch directly Flux® Skew.

6.3 Particularities in building and to exporting a model to Flux® SKEW environment

A user who wants to build and export a model to Flux® SKEW has to follow the same steps and recommendations as with the function “FLUX 2D”.

The main particularity of function “FLUX SKEW” is that the “**Skew number of layers**” is an input, that must be defined. Its default value is 3.

Even if the design of the machine is defined with “continuous skew”, the “**Skew number of layers**” is necessary for Flux® to define the finite elements model in the FLUX SKEW environment. A high number of layers gives more accurate finite elements computations. However, it needs higher computation time. For that purpose, the value 3 is a good compromise between accuracy and speed.



Motor Factory – EXPORT AREA – Export a model for Flux® SKEW

1	Tab to define the initial conditions for the simulation process in Flux® SKEW environment
2	Settings like thermal and mechanical conditions can be defined
3	User inputs dealing with the considered test can be defined
4	The tab corresponding to advanced parameters can be expanded. Advanced parameters can also be defined, if needed.
5	Button to validate the previous choices

7 BUILD AND EXPORT A MODEL IN ALTAIR® FLUX® 3D ENVIRONMENT

7.1 Overview


The aim of this export is to provide a python file which allows to get a full parametrized model ready to be used in Altair® Flux® 3D environment.

In the current version of FluxMotor® the only application type available for Flux® 3D export is STATIC for three-phase inner rotor SMPM. Transient export and outer rotor /polyphase machines will be addressed in a future version.

Application	Model family	Package	Convention	Model / Test
STATIC	Without solving scenario	Current source	Motor & Generator	Basic model

The following section gives a short description of the process to export the model into Flux® 3D environment.

7.2 Area to build and to export a model to Flux® 3D environment



Motor Factory – EXPORT AREA – Export model for Flux® 3D environment

1	Selection of the EXPORT area of Motor Factory.
2	Access to the area in which a model for Flux® 3D environment can be made
3	Zone to visualize the overview of the selected model to be exported
4	Click on the tab to select the application (in the current version, only STATIC is available)
5	Different lengths for rotor, stator and magnets can be chosen by clicking on this tab.
6	3 steps to build the model to be exported for Flux® 3D environment
7	Button to validate inputs and export the python file for building the model in Flux® 3D environment.
8	Buttons to export the python file for building the model in Flux® 3D environment or to launch directly Flux® 3D.

7.3 Particularities in building and exporting a model to Flux® 3D environment

A user who wants to build and export a model to Flux® 3D has to follow the same steps and recommendations, as with the function “FLUX 2D”.

The main particularity of function “FLUX 3D” is that rotor, stator and magnets axial lengths are the inputs, that must be defined. Their default values equals the machine length defined in “Design”. These three lengths can be different.

Motor Factory – EXPORT AREA – Export a model for Flux® 3D

1	Tab selector to define general export parameters and axial lengths in Flux® 3D environment
2	Table containing stator topology features. Stator length may be modified.
3	Table containing rotor topology features. Rotor and magnets lengths may be modified.
4	To reduce computation time in Flux® 3D, full geometry and symmetry options are offered. By default, these options are set to assure minimum computation time without accuracy loss.
5	Button to validate the previous choices

Note 1: Default values for rotor, stator and magnet lengths are equal to the machine design length. However, a change in these values only affect the Flux® 3D export and it **never** changes the design length value.

Note 2: Symmetry allows to represent only half of the topology in the axial direction, saving the simulation time. This option is available only when all the dimensions are equal on both sides of the machine (Connection Side and Opposite Connection Side), especially for the end winding dimensions.

A warning message is provided in the “Design environment” each time an asymmetric topology is defined, to inform the user that the Flux® 3D export input “symmetry” has been set to “No”. This also occurs when the asymmetry is due to the end shafts, even if they are not represented in the 3D environment.

Note 3: Export to Flux® 3D is not available for skewed topologies. In this case Flux® SKEW export is recommended.

8 BUILD AND EXPORT A MODEL IN ALTAIR® FLOW SIMULATOR™ ENVIRONMENT


8.1 Overview

The aim of this export is to provide a “.flo” file which allows to get a machine model ready to be used in Altair® Flow Simulator™ environment which will allow to represent the thermal behavior of the machine through a customizable lumped thermal parameter model coupled with a flow network when necessary.

In the current version of FluxMotor® the only application type available for Flow Simulator® export is the steady state thermal analysis for three-phase inner rotor SMPM. Thermal transient export and more machine types will be addressed in future versions.

The following section gives a short description of the process to export the model into Flow Simulator™ environment.

8.2 Area to build and to export a model to Flow Simulator™ environment



Motor Factory – EXPORT AREA – Export model for Flow Simulator™ environment

1	Selection of the EXPORT area of Motor Factory.
2	Access to the area in which a model for Flow Simulator™ environment can be made
3	Zone to visualize the overview of the selected model to be exported. Currently, it warns that this export is in BETA version.
4	3 steps to build the model to be exported for Flow Simulator™ environment
5	Button to validate the inputs.
6	Buttons to export the “.flo” file for building the model in Flow Simulator™ environment or to launch directly Flow Simulator™

Note 1: “. flo” files are text files used by Flow Simulator™ to stock all the information about a project, e.g., the background images, the thermal/flow network components including their values, placements, etc.

8.3 Steps to build an export Flow Simulator™

8.3.1 Introduction

In EXPORT / ADVANCED TOOLS / FLOW SIMULATOR area, 3 steps are needed to build and export data:

- 1) Define the thermal model to be exported into Flow Simulator™. For the moment only the thermal steady state model is available.
- 2) Define the test configuration, that means the user inputs/outputs parameters needed to perform the test (settings and user inputs of the considered test)
- 3) Define the export information.


8.3.2 Test selection

In the current version of FluxMotor®, one test can be selected:

- Characterization / Thermal – Motor & Generator / Steady State

8.3.3 Test configuration

After selecting the test, the corresponding test inputs (settings and user inputs) must be defined. This allows to define the initial conditions for the simulation process in Flow Simulator™ environment.




Motor Factory – EXPORT AREA – Export a model for Flux® 2D -

1	Tab to define the initial conditions for the simulation process in Flow Simulator™ environment
2	Access to thermal settings
3	User inputs and settings dealing with the considered test should be defined
4	Buttons to validate or cancel thermal settings
5	Buttons to validate inputs or to return to default values.

8.3.4 Export information

The last step for building a model for Flow Simulator™ is to define the export information. There are two data to be defined:


- The name of the ".flo" file which will build the model in Flow Simulator™ environment.
- The folder in which the provided file will be stored.



Motor Factory – EXPORT AREA – Export model for Flow Simulator™ – Export information

1	Tab to be expanded to define export information for Flow Simulator™
2	Area in which the export parameters to be defined are listed
3	Button to validate the previous choices
4	Button to finalize the export of the model. It opens the folder where the “.flo” file is generated.
5	Button to finalize the export of the model. It launches Flow Simulator™ and builds the model.

Note 1: When data is missing / wrong in third table; “Export information” for instance, an error message is displayed in the red colored font which indicates what data is missing / wrong. If needed information is missing, exporting a model is not allowed.



Motor Factory – EXPORT AREA – Export model for Flow Simulator™ – Error message

1	Error message displayed in the red colored font
2	The button to export the model is not active if the needed data are missing

Note: Exporting a model to Flow Simulator™ (i.e. provide the “.flo” file to build the model) can take a few seconds, since it is necessary to run some pre-calculations to build the lumped parameter thermal model.

8.4 Available models to be exported and user inputs

8.4.1 Overview

In the current version only one Flow Simulator™ export is available the steady state thermal analysis for three-phase inner rotor SMPM. Thermal transient export and more machine types will be addressed in future versions.

8.4.2 Characterization – Thermal -Motor & Generator – Steady State

8.4.2.1 Positioning and objective

The aim of this export is to represent the steady state thermal behavior of the machine through a customizable lumped thermal parameter model coupled with a flow network when necessary.

The resulting model is a 3D representation of a steady state thermal circuit built in Flow Simulator™, it corresponds to the thermal model used in Flux Motor® to run both, thermal and coupled tests.

The following section describes all the user inputs and settings to initialize the exported model.

8.4.2.2 Settings

One button gives access to the following setting definition:

- External fluid temperature

For more details, refer to the section dealing with the test settings.

8.4.2.3 Standard inputs

1) Speed

The speed of the machine to be considered.

2) Set of losses

The losses to be defined are the following ones:

- Stator Joule losses
- Stator iron losses
- Magnet losses
- Rotor iron losses
- Mechanical losses

8.4.2.4 Advanced inputs

There are no advanced inputs required for this export.

9 EXPORT TO SYSTEM

9.1 Overview

The area SYSTEM, in the EXPORT environment of Motor Factory, allows exporting data like constants, curves and maps in lookup table (LUT) formats, such as FMU and MAT format files.

In the current version, the test Characterization/Model/Maps can be selected for exporting the data.


Constants, curves and maps” given in J_d - J_q plane, for characterizing the 3-Phase synchronous machines with permanent magnets are computed and exported.

These files can be imported directly into environments like Altair® Activate®, Altair® Compose® or Altair® PSIM® as binary variables files (.mat) or inside block functions, ready to be integrated into schemes to represent the model of the corresponding rotating electrical machine.

These functionalities are useful to represent the machine at the system level. Therefore, electrical machine and other system components, such as the drive and the control command, can be represented and simulated altogether into the same area.

Note: This functionality is not implemented for polyphase machines. It will be addressed in a future version.

9.2 Area to export LUT



Motor Factory – EXPORT AREA – Export data in LUT formats.

1	Selection of the EXPORT area of Motor Factory.
2	Access the area (SYSTEM) in which data can be exported in lookup table (LUT) formats.
3	Zone to visualize either the overview of the selected test
4	3 steps to compute and to export LUT data
5	Button to validate inputs, display a preview and export the data.

9.3 Steps to build an export LUT

9.3.1 Introduction

In EXPORT / ADVANCED TOOLS / SYSTEM area, 3 steps are needed to build and export data:

- 3) Select the test which will be performed for building data to be exported.
- 4) Define the test configuration, that means the user inputs/outputs parameters needed to perform the test (settings and user inputs of the considered test)
- 5) Define the export type (FMU or MAT formats) and information.


9.3.2 Test selection

In the current version of FluxMotor®, one test can be selected:

- Characterization / Model / Motor / Maps

9.3.3 Test configuration

After selecting a test, the corresponding test inputs (settings and user inputs) must be defined. This allows to define the initial conditions for testing.



Motor Factory – EXPORT AREA – SYSTEM – LUT / Test configuration for Characterization / Model / Motor / Maps

1	Overview of the selected test is displayed
2	User inputs can be defined in the test area.
3	User's inputs to export data based on 1, 2 or 4 quadrants
4	User's inputs to export data with respect to the rotor position dependency.

Note: The user help information about the test parameters is defined in the user help guide of the corresponding test. Please refer to the corresponding section.

Note: Operating quadrants

Export / System LUT (Activate or PSIM) allows exporting data based on 1, 2 or 4 quadrants

This user's inputs define the quadrants in the $J_d - J_q$ plane, where the test will be carried out. By default, the only considered quadrant is the 2nd one (i.e., the grid is only defined for negative values of the current in the d axis and positive ones in the q axis). This corresponds to the motor behavior of the machine.

Options allow computing and displaying 1, 2 or 4 quadrants.

By default, the only considered quadrant is the 2nd one (i.e., the grid is only defined for negative values of the current in the d axis and positive ones in the q axis). This corresponds to the motor behavior of the machine.
 The other possible values for this input are: “2nd and 3rd “, “1st and 2nd “and “all”.

Note: Rotor position dependency

Export / System LUT (Activate or PSIM) allows exporting data with respect to the rotor position dependency.

This user’s input defines the rotor position dependency, where the test will be carried out. By default, the rotor position dependency is set to “No” but it can be set to “Yes”. In this case the computation will be done in the $J_d - J_q$ plane with an additional third axis corresponding to the rotor position θ_r .


In case the rotor dependency is set to “Yes”, whatever the operating quadrant choice, the finite element computation is done over all selected quadrants (in case the rotor dependency is set to “No”, symmetries are used).

9.3.4 Export information

The last step for building and exporting data in FMU format files is to define the export information.

Three inputs must be defined:

- The name of the directory in which the created files will be stored
- The format of the file to be exported. Three options are available: FMU for Activate, FMU generic and MAT file - for Activate and PSIM.
- The destination folder in which the previous directory will be located



Motor Factory – EXPORT AREA – SYSTEM – LUT / Export information

1	Tab to be expanded to define the export information.
2	Area in which the export information of parameters to be defined are listed
3	Button to validate the previous choices
4	Button to finalize the export of the data files. One click opens the folder where the directory is located

9.4 FMU format files

9.4.1 Compatibility

Two packages of FMU format files are automatically provided, one dedicated to Activate® and another one compatible with other system simulation tools.

Hence, the user will be able to select the required system simulation tool without any problem of compatibility. One of the main differences between the two files is how the units are managed in the name labels (See below illustrations).

The screenshot shows the Altair FluxMotor interface with the 'fmi' logo and 'FUNCTIONAL MOCK-UP INTERFACE' text. A list of export options is shown: FMData, FMU_ACTIVATE (highlighted), and FMU_GENERIC. An arrow points to the 'FMU Information' dialog box.

Attribute	Value
General Information	
fmiVersion	2.0
modelName	FMUData_DSStatInductance
description	Altair Engineering FMUData_DSStatInductance
generationTool	Altair Engineering - All right reserved - Versio...
generationDateAndTime	2021-09-03T11:51:01Z
numberOfEventIndicators	0
variableNamingConvention	structured
Model Exchange	
modelIdentifier	FMUData_DSStatInductance

Name	Index	Variable	Description
Jd(A)	1	name	Jd(A)
Jq(A)	2	valueReference	1
StLd(H)	3	causality	input
interpol	4	variability	continuous
Current_definition_mode	5	datatype	Real
Max_line_current_rms_A	6	declaredType	Modelica Electrical Analog.Interfaces.Pin
Max_current_dens_rms_A/mm2	7		
No_comp_for_id_lq	8		
Maximum_speed_rpm	9		
No_comp_for_speed	10		
Thermal_solving	11		
Winding_straight_part_temperature_1C	12		
CS_end_winding_temperature_1C	13		
OCS_end_winding_temperature_1C	14		
Magnet_temperature_Tmag_1C	15		

Exported FMU format files dedicated to Activate®

The screenshot shows the Altair FluxMotor interface with the 'fmi' logo and 'FUNCTIONAL MOCK-UP INTERFACE' text. A list of export options is shown: FMData, FMU_ACTIVATE, and FMU_GENERIC (highlighted). An arrow points to the 'FMU Information' dialog box.

Attribute	Value
General Information	
fmiVersion	2.0
modelName	FMUData_DSStatInductance
description	Altair Engineering FMUData_DSStatInductance
generationTool	Altair Engineering - All right reserved - Versio...
generationDateAndTime	2021-09-03T11:50:56Z
numberOfEventIndicators	0
variableNamingConvention	structured
Model Exchange	
modelIdentifier	FMUData_DSStatInductance

Name	Index	Variable	Description
Jd_A	1	name	Jd_A
Jq_A	2	valueReference	1
StLd_H	3	causality	input
interpol	4	variability	continuous
Current_definition_mode	5	datatype	Real
Max_line_current_rms_A	6	declaredType	Modelica Electrical Analog.Interfaces.Pin
Max_current_dens_rms_A_per_mm2	7		
No_comp_for_id_lq	8		
Maximum_speed_rpm	9		
No_comp_for_speed	10		
Thermal_solving	11		
Winding_straight_part_temperature_d	12		
CS_end_winding_temperature_deg_C	13		
OCS_end_winding_temperature_deg_C	14		
Magnet_temperature_Tmag_deg_C	15		
Rotor_initial_position_deg	16		

Exported FMU format files (Generic) compatible with other system simulation tools

9.4.2 A C/C++ compiler is needed

9.4.2.1 C/C++ compiler / System requirements

FluxMotor® requires a C/C++ compiler to perform some operation for creating FMU blocks.

Here is the list of the Visual Studio compilers supported:

Microsoft® Visual Studio 2019, Community, Professional, Enterprise

Microsoft® Visual Studio 2017, Community, Professional, Enterprise

Microsoft® Visual Studio 2019/2017/2015: Build Tools

Note: the option for **Windows 10 SDK** must be selected

Microsoft® Visual Studio C++ 2015 (VC 14.0 Express, Community and Professional)


Important Remark

The table above proposes different versions of Microsoft Visual Studio. Make sure the version you install is approved by your IT department and you have the right license (e.g. if you decide to use Professional Edition, a license is required)

9.4.2.2 Access path of the C/C++ Compiler

Once the C/C++ Compiler is installed on the computer, its access path must be specified in the user's preferences.

Note: When opening FluxMotor®, if a C/C++ Compiler is already installed on the computer, the corresponding install path is automatically written in the user's preferences.



FluxMotor® / Supervisor / User's preferences / Location of the C/C++ Compiler

1	The Preferences dialog box is opened from the FluxMotor® supervisor.
2	Second tab is Path Preferences.
3	Define the location of the C/C++ Compiler on the computer

Here is below a list of files to select in the installation directory (path) according to the Visual Studio version installed:

Visual Studio 2019, Community	C:\Program Files (x86)\Microsoft Visual Studio\2019\Community\VC\Auxiliary\Build\vcvarsall.bat
Visual Studio 2019, Professional	C:\Program Files (x86)\Microsoft Visual Studio\2019\Professional\VC\Auxiliary\Build\vcvarsall.bat
Visual Studio 2019, Enterprise	C:\Program Files (x86)\Microsoft Visual Studio\2019\Enterprise\VC\Auxiliary\Build\vcvarsall.bat
Visual Studio 2017, Community	C:\Program Files (x86)\Microsoft Visual Studio\2017\Community\VC\Auxiliary\Build\vcvarsall.bat
Visual Studio 2017, Professional	C:\Program Files (x86)\Microsoft Visual Studio\2017\Professional\VC\Auxiliary\Build\vcvarsall.bat
Visual Studio 2017, Enterprise	C:\Program Files (x86)\Microsoft Visual Studio\2017\Enterprise\VC\Auxiliary\Build\vcvarsall.bat
Microsoft® Visual Studio C++ 2015 Express	C:\Program Files (x86)\Microsoft Visual Studio\14.0\VC\Build\vcvarsall.bat
Microsoft® Visual Studio C++ 2015 Community	C:\Program Files (x86)\Microsoft Visual Studio\14.0\VC\Build\vcvarsall.bat
Microsoft® Visual Studio C++ 2015 Professional	C:\Program Files (x86)\Microsoft Visual Studio\14.0\VC\Build\vcvarsall.bat
Microsoft® Visual Studio 2019, Build Tools	C:\Program Files (x86)\Microsoft Visual Studio\2019\BuildTools\VC\Auxiliary\Build\vcvarsall.bat
Microsoft® Visual Studio 2017, Build Tools	C:\Program Files (x86)\Microsoft Visual Studio\2017\BuildTools\VC\Auxiliary\Build\vcvarsall.bat

Note that the executable command is detected if the Visual Studio is already installed before or if the preference is set to an empty value and then reopening the preference.

9.4.3 Import FMU data in Altair® Activate®


Once FMU files are generated by FluxMotor®, these can be imported in environments like Activate®. This section explains how FMU files generated from FluxMotor® are used in Activate®. The FMU file of the D-axis flux is taken as an example.

First, Activate® is opened.

Either start creating a new project via a new modeling window or open an existing scm file.

To use FMU files from FluxMotor®, locate the FMU block in the palettes of the System library.

- 1) Select View > Palette Browser




The Palette Browser displays the installed library palettes.

- 2) Double-click Activate® > CoSimulation.
The Palette Browser displays the blocks available in the CoSimulation palette.
- 3) Select the FMU block, then drag and drop it into the modeling window.

One can also write down “FMU” in the quick search field.

- 4) Double-click on the FMU dragged in the modeling window, or right-click, and from the context menu, select Parameters.




Then:

- In General parameters > FMU filename, indicates the path to the D-axis flux FMU (the directory in which the FMU file is located).
- All the information regarding the D-axis flux FMU appears along with a new content under the name parameters appears. In this area, you can set the boundaries of the quadrant by choosing a value from 0 to 3. These boundaries reflect the FMU response when the user is outside the quadrant in which the calculations were made.

The meaning of each value is listed in the table that follows:

Value	Meaning
0	NAN
1	Zero
2	Hold
3	Linear extrapolation

All the information related to the resolution of the test map can be seen by clicking on the info tab.



The FMU generated will have its inputs and output. The D-axis flux FMU in Activate® will look like this:



Along with FMU files, an oml file, that contains important constant values of the test map is generated. These values can be loaded and used in the Activate® model by executing the oml file.

This oml file could be read in Activate® diagram home by indicating its path, and using the function execution as follow:

```
run('D:\UserFolder\Export_FMUI\FMU_AD\oml\constants.oml')
```


Command History		Variable Browser		Session Information	
Name	Value	Type	Scope		
ANGPOS_ROTOR_DEG	45	number	Base		
AXIS_MAGNET_TEMP	150	number	Base		
Catalog_Name	User_SM_PM_IR_3Ph	string	Base		
FLUX_D	<matrix(1x25)>	matrix	Base		
FLUX_ID0	[0.0671220325 0.0676971718 0.0632808409 ...	matrix	Base		
FLUX_Q	<matrix(1x25)>	matrix	Base		
Family	Synchronous	string	Base		
ID_PEAK	[-424.264068711929 -318.198051533946 -21...	matrix	Base		
IQ_PEAK	[0 106.066017177982 212.132034355964 318...	matrix	Base		
J_inertia	0.0299335738386677	number	Base		
LD_DYN_vs_ID	<matrix(1x25)>	matrix	Base		
LD_DYN_vs_IQ	<matrix(1x25)>	matrix	Base		
LD_STAT_vs_ID	<matrix(1x25)>	matrix	Base		
LD_STAT_vs_IQ	<matrix(1x25)>	matrix	Base		
LOSS_IRON	<matrix(1x125)>	matrix	Base		
LOSS_JOULE	<matrix(1x25)>	matrix	Base		
LOSS_MECHANICAL	<matrix(1x200)>	matrix	Base		
LQ_DYN_vs_ID	<matrix(1x25)>	matrix	Base		
LQ_DYN_vs_IQ	<matrix(1x25)>	matrix	Base		
LQ_STAT_vs_ID	<matrix(1x25)>	matrix	Base		
LQ_STAT_vs_IQ	<matrix(1x25)>	matrix	Base		
L_end_winding	1.11642517844301e-05	number	Base		
Motor_Name	Nissan_Leaf	string	Base		
No_phases	3.0	string	Base		
Phi_M	0.0671220325	number	Base		
R_phase	0.0154984181044671	number	Base		
SPEED_RPM	[1200 2400 3600 4800 6000]	matrix	Base		
Software_source	AltairFluxMotor	string	Base		
Sub_type	Inner rotor	string	Base		
TEST_CURRENT_DEFINITION_MO...	CURRENT	string	Base		
TEST_CURRENT_DENSITY_RMS	7	number	Base		
TEST_CURRENT_LINE_RMS	300	number	Base		
TEST_MAXIMUM_SPEED	6000	number	Base		
TEST_NO_COMPTUTATIONS_FOR...	5	number	Base		
TEST_NO_COMPTUTATIONS_FOR...	5	number	Base		
THERMAL_MAGNET_SOLVING_MO...	MAGNET_CONSTANT_TEMPERATURE	string	Base		
TORQUE	<matrix(1x25)>	matrix	Base		
T_ACTIVE_LENGTH_WINDING_C	100	number	Base		
T_CS_END_WINDING_C	100	number	Base		
T_MAGNET_C	150	number	Base		
T_OCS_END_WINDING_C	100	number	Base		
Type	Permanent magnet	string	Base		
Version	2022.2.0	string	Base		
initial_angle_rotor_deg	45	number	Base		
num_pole_pairs	4	number	Base		