
# **CADFEKO** Quick Tips



## 1. File Menu

 Displays general commands (Save As, Import, Export, Check for Updates, Settings, etc.)

# 2. Quick Access and Launch Toolbar

 Global access to common tasks (including Save, Undo, launch Feko Solver, access help)

#### 3. Search Bar

- · Search for operations or help
- · Quick access to advanced operations

#### 4. Ribbon

- Default tabs (Construct, Mesh, Solve/Run, etc.)
- · Contextual tabs (e.g. Display Options)

# 5. Configurations List

- · Add and manage solution configurations
- · Select configuration

# 6. Model Tree

 Context menus to manage geometry objects, meshes, solution settings, parametric variables

## 7. Details Tree

- · Geometry object details (edges, faces, regions)
- · Apply custom solution and mesh settings

#### 8. View (3D)

 Visualise geometry, meshes, solution settings and output requests (far and near fields)

#### 9. Notification Centre

- · Performs CEM validation
- · Highlight problems in model


# 10. Status Bar

 Global access to macro recording, auto meshing, display settings, selection, tools, model unit, etc.

Altair Feko



# **CADFEKO** Quick Tips






# **CADFEKO Meshing Guidelines**

- · Global mesh sizes are set in the meshing dialog (Coarse, Standard, Fine or Custom)
- · Local mesh sizes can be specified for individual components in the details tree
- · Point, polyline and adaptive mesh refinement rules can be defined to mesh finer in certain areas (user-defined or error estimation based)
- · To ensure a good mesh, there should be no overlapping faces or disconnected parts. Use the union operation to ensure that parts are connected:



Ctrl + Click Select parts








# **Macro Recording**


- · Use macro recording to record actions
- · Play the script to automate process and to perform repetitive actions faster



# **CADFEKO Point Entry and Snapping**

- · Quick entry of field values in dialogs based on 3D view and model tree
- · Yellow background when point entry is possible
- 3D View: Snapping and point entry preview activated by holding down Ctrl + Shift
- Model Tree: Variable/named point value added to active field with Ctrl + Shift + Click







Ctrl + Shift + Click Point entry

Altair Feko

