



Altair® Twin Activate™ 2025.1 Pneumatics Library v2.0

README

This is a Altair Pneumatics Library (AltairPneumatics) installation package.

It contains the following files:

- 'ReadMe.txt': Text version of this file.
- 'ReleaseNotes.txt': Short descriptions of updates, fixes and known issues.
- 'AltairPneumatics': a ready-to-use Twin Activate library with pneumatic components.

See below for installation instructions.

INSTALLATION OF ALTAIRPNEUMATICS

- Start Twin Activate, Release 2025 or newer
- Remove a previous version of AltairPneumatics from Extension Manager (if any exists)
- Unzip AltairPneumatics.zip to an arbitrary path
- Add AltairPneumatics folder as new Extension in Extension Manager

WHAT WILL BE INSTALLED

- The AltairPneumatics library in the Palette
- Examples of AltairPneumatics components usage in Demo Browser
(if not visible, please select View > Demo Browser)
- Documentation available by right-click > Help on any block of the library

